

LUXPRO PSD111a+  
Non Programmable Thermostat




Reset Button

Set Display To Vertical Or Horizontal

Lux Pro PSD111a+  
Non Programmable

This Should Be  
Set to Elec

Leave Set  
To RH=RC



Reset Button

Set Display To Vertical Or Horizontal

Lux Pro PSD111a+  
Non Programmable

This Should Be  
Set to Elec

Leave Set  
To RH=RC

