


Leave The Small Jumper Wire That Connects RH and RC



Leave The Small Jumper Wire That Connects RH and RC